

1. Tolerance of the outside diameter in inches and millimeters

Inches:

Diameter of the opening	Tolerances		Tolerances	
	of the metal shell	of the rubber outer diameter	of the metal shell	of the rubber outer diameter
Под 1,000	+ 0,004	+ 0,006	+/- 0,002	+/- 0,003
1,001 – 2,000	+ 0,004	+ 0,007	+/- 0,002	+/- 0,003
2,001 – 3,000	+ 0,004	+ 0,008	+/- 0,002	+/- 0,003
3,001 – 4,000	+ 0,005	+ 0,010	+/- 0,002	+/- 0,004
4,001 – 6,000	+ 0,005	+ 0,010	+ 0,003 - 0,002	+/- 0,004
6,001 – 8,000	+ 0,006	+ 0,010	+ 0,004 - 0,002	+/- 0,004
8,001 – 10,000	+ 0,008	+ 0,010	+ 0,006 - 0,002	+/- 0,004
10,001 – 20,000	+ 0,008	+ 0,010	+ 0,010 - 0,002	+/- 0,004

Millimeters:

Diameter of the opening	of the metal shell	of the rubber outer diameter
Под 50,00	+ 0,10/+ 0,20	+ 0,15/ 0,30
50,01 – 80,00	+ 0,13/+ 0,23	+ 0,20/ 0,35
80,01 – 12,00	+ 0,15/+ 0,25	+ 0,20/ 0,35
120,01 – 180,00	+ 0,18/+ 0,28	+ 0,25/ 0,45
180,01 – 315,00	+ 0,20/+ 0,30	+ 0,25/ 0,45
315,00 – 500,00	+ 0,23/+ 0,35	+ 0,30/ 0,55

Width tolerances:

Inch	Tolerance	Millimeter	Tolerances
Under 0,313	+/- 0,008	Under 8	+/- 0,20
0,314 – 0,472	+/- 0,012	8,01 – 12	+/- 0,30
0,473 – 0,709	+/- 0,016	12,01 – 18	+/- 0,40
Over 0,710	+/- 0,020	Over 18	+/- 0,50

Tolerance and authorized eccentric outer diameter of the seal in millimeters:

Diameter of the opening	Tolerances		Allowed eccentric
	of the metal shell	of the rubber outer diameter	
Unde 50	+ 0,10 / + 0,20	+ 0,15 / + 0,30	0,25
50,01 - 80	+ 0,13 / + 0,23	+ 0,20 / + 0,35	0,35
80,01 – 120	+ 0,15 / + 0,25	+ 0,20 / 0,35	0,50
120,01 – 180	+ 0,18 / + 0,28	+ 0,25 / 0,45	0,65
180,01 – 300	+ 0,20 / + 0,30	+ 0,25 / + 0,45	0,80
300,01 - 500	+ 0,23 / + 0,35	+ 0,30 / + 0,55	1,00